恆業機械
HENGYE MACHINERY

HY-W-JH HY-W-SJ
HY-94-3JLB HY-94-3JL

6"

电脑无梭多针绗缝机 • 多跨图册

COMPUTERIZED CHAIN STITCH MULTI-NEEDLE QUILTING MACHINE (TACK AND JUMP) PATTERNS BOOK

Http://www.hengyejixie.com
Http://www.hengyemachinery.com
E-mail:hengye@hengyejixie.com


0 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


1 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


2 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


3 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


4 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


5 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →


6 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


7 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


8 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


9 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


10 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


11 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →


12 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


13 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


14 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


15 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


16 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


17 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


18 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


19 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


20 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


21 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


22 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


23 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


24 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


25 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


26 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


27
Dist:
0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


28 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


29 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


30 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


31 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→


32 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


33 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→


34 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


35 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


36 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→


#37 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


38 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


39 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


40 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


41 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →


42 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


43 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →


44 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


45 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


46 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "

47 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


48 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


49 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


50 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


51 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


52 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


53 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


54 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


55 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


56 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


57 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


58 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


59 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


60 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


61 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


62 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


63 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


64 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


65 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


66 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →


67 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


68 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


69 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →


70 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


71 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


72 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


73 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


74 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


75 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


76 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


77 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


78 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


79 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


80 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


81 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


82 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


83 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →


84 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


85 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


86 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


87 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


88 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


89 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


90 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


91 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →


92 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →


93 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


94 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


95 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


96 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


97 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


98 Dist: 0 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →


99 Dist: 0
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6"


#100 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#101 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →


#102 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#103 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#104 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#105 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#106 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#107 Dist: 152 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#108 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →


#109 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#110 Dis
305
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


#111 Dist: 230 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#112 Dist:
152
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+


#113 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#114 Dist:
305
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


#115 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#116 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#117 Dist: 304 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#118 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#119 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#120 Dist:
305
<
>
CLR.
Swap
6Inch
OK
Cancel
-
+
←
↑
↓
→
6 "


#121 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#122 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#123 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#124 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#125 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#126 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#127 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#128 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#129 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#130 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#131 Dist: 126 < > CLR. Swap 6Incl OK Cancel - + ← ↑ ↓ →
6 "


#132 Dist: 152 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#133 Dist: 152 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#134 Dist: 152 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#135 Dist: 152 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#136 Dist: 152 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#137 Dist: 152 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#138 Dist: 152 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#139 Dist: 152 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#140 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#141 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#142 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#143 Dist: 152 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#144 Dist: 152 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#145 Dist: 100 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#146 Dist: 360 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "


#147 Dist: 200 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#148 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#149 Dist: 305 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6"


#150 Dist: 215 < > CLR. Swap 6Inch OK Cancel - + ← ↑ ↓ →
6 "

恆業機械廠
HENGYE MACHINERY FACTORY
厂址：中国广东省东莞市东城温塘温增路16号
邮编：523121
电话：0769-22264807　22291362
传真：0769-22663246
网址：//www.hengyejixie.com
邮箱：hengye@hengyejixie.com

Address:16＃,Wenzeng Rd.Wentang Dongcheng District, Dongguan City,Guangdong Province, 523121, P.R.China,
Tel :+86-769-22264807　22291362
Fax:+86-769-22663246
Http://www.hengyejixie.com
E-mail:hengye@hengyejixie.com

UKAS QUALITY MANAGEMENT
014
ISO9001 : 2000
CE